# Parts List Standard Breakdown

## AMSCO Scientific Eagle® Century Series SL Sterilizer

(10-2-98)

P-387345-865 Rev.3

## A WORD FROM STERIS

#### Advisory

A summary of the safety precautions to be observed when servicing this equipment can be found in Section 1 of The Service Procedure Manual and behind the upper access panel of the unit. Do not operate or service the sterilizer until you have become familiar with this information.

This sterilizer is not designed to process flammable liquids nor liquids in containers that are not designed for sterilization. Any alteration of the sterilizer which affects its operation will void the warranty and could violate state and local regulations and jeopardize insurance coverage.

## **TABLE OF CONTENTS**

	Section	Paragraph	Page
		List of Illustrations and Contents	
Introduction			1
Control Com	ponents		
	Control Box		2
Figure 2.	Control Board		Α
Figure 3.	I/O Board		۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰
Figure 4.	Door Components		o
Figure 5.	Door Pressure Lock	Assembly	O
Figure 6.	Bridge Assembly an	nd Rack & Shelving Assembly	
Figure 7.	Ontional Loading Ca	ar	12
Figure 8.		arriage	

Significant assemblies and components of the Eagle® Century SL Series Sterilizers are illustrated and identified in this booklet. The part number, description and schematic designation (where applicable) are given. Each indentation in the description represents the assembly level.

This manual is provided to STERIS® customers and STERIS® service technicians to enhance the ordering of maintenance parts for the AMSCO® Eagle® Century SL Sterilizers. This manual includes parts required for routine calibration of the machine by a qualified service technician. To order maintenance parts or identify hardware not found in this manual, please call STERIS® Customer Service at (800) 333-8848 for assistance.

Parts which will require recalibration of the machine after replacement are marked in this manual by an asterisk(\*). STERIS® recommends the customer call for the assistance of an STERIS® technician to perform this work.

The customer maintenance person should refer to the Eagle Century Series Sterilizer Service and Maintenance Procedure Manual for installation of parts not marked by an asterisk, which may require special attention or adjustments during installation.

#### How to Use the Illustrated Parts List:

- Determine the function and application of the part required. Consult the list of illustrations (on the page facing this one), select the most appropriate title and note the page number.
- 2. Turn to the selected page and locate the desired part on the illustration.
- From the illustration, obtain the item number assigned to the desired part.
   Refer to the accompanying tabular list (usually on the facing page) for the STERIS® order number and description for the part.




Figure 1a. Standard Century Control Box

Control Box

	Call STER	IIS® Customer Service For Ordering Parts 1-800-333-8848
ITEM NO.	PART NUMBER	DESCRIPTION
1 1	136810 -006	POWER SUPPLY
2	84121 -002	NUT, KEPS #6
3	93918 -080	WIRE HARNESS J2/FAN
4	136809 -744	WIRE HARNESS J4/J16
★ 5	146656 -185	BOARD, CONTROL ASSEMBLY (See Fig. 2)
6	146657 -779	BOARD, CONNECTOR ASSEMBLY
7	93918 -079	FAN, COOLING
8	129367 -525	FILTER, AIR
9	136809 -737	GASKET, CONTROL BOX
10	136809 -743	FAN, ADAPTER
11	93908 -039	SCREW, SEMS #6 - 32 x 3/8" LG.
<b>★</b> 12	366071 -996	I/O BOARD ASSEMBLY
	129361 -870	■ RELAY (solid state)
	129367 -617	■ RELAY (mechanical)
	129363 -928	■ FUSE
13	136809 -746	WIRE HARNESS J3B/J15B
14	136809 -745	WIRE HARNESS J3A/J15A
15	129367 -517	DECAL, SWITCH
16	93911 -576	SWITCH, CONTROL (SW1)
17	93910 -584	FILTER, LINE
18	764317 -463	FUSE, 5A (F3)
19	129361 -158	BLOCK, TERMINAL
20	3966 -041	SCREW, RD., HD. #6-32 x 1-1/4" LG.
21	19675 -041	LOCKWASHER, #6
22	129367 -492	LABEL, TERMINAL BLOCK
23	146657 -777	HOUSING, CONTROL
24	93918 -352	HOSE, CONTROL BOX (Not Shown)
25	150371 -001	DECAL, DISCONNECT POWER (Not Shown)
26	93918 -187	LABEL, WARNING BURN HAZARD (Not Shown)
27	93918 -457	LABEL, MAIN POWER (Not Shown)
28	93918 -099	LABEL, WARNING SHOCK/BURN (Not Shown)
<b>*</b> 29	146659 -008	I/O BOARD ASSEMBLY
	129361 -870	RELAY (solid state)
<b>-</b>	129363 -928	■ FUSE
★30	146659 -003	HALF SIZE ANALOG BOARD
(ama) = 15	or	
(optional)	146659 -029	FULL SIZE ANALOG BOARD
		★
		Note dip switch and jumper settings (See Service and Maintenance Procedure for settings.)




Figure 1b. Century EXP Control Box

EXP Control Box ASSEMBLY 146659-045

TEM NO.   NUMBER   DESCRIPTION
2 146659 -032 BACKPLANE 3 366072 -387 POWER SUPPLY 4 338521 -697 ENCLOSURE 5 356256 -488 MOUNTING PLATE 6 93915 -093 RAIL, DIN 7 93922 -049 TERMINAL BLOCK 8 338521 -698 TERMINAL BLOCK 9 93922 -023 TERMINAL BLOCK 10 93910 -584 FILTER, ELECTRIC 11 146656 -185 CONTROL BOARD 12 146659 -029 ANALOG BOARD 13 366071 -996 I/O BOARD 14 146659 -008 I/O BOARD 15 356256 -484 SWITCH ASSEMBLY 16 338521 -700 WIRING DUCT 17 338521 -702 DUCT COVER 18 338521 -699 WIRING DUCT
19





Figure 2. Control Board

Control Board

Control Board				
		IIS® Customer Service For Ordering Parts 1-800-333-8848		
ITEM NO.	PART NUMBER	DESCRIPTION		
1 *2 3	93915 -047 146656 -185	BATTERY, SMART, U2 DS1260 EPROM SET CONTROL BOARD ASSEMBLY (INCLUDES 4 UNPROGRAMMED EPROMS)  *Contact STERIS* for replacements.		




NOTE: Item 2 is replaced by item 1 for board P/N 366071-996.

Figure 3. I/O Board

I/O Board

Call STERIS® Customer Service For Ordering Parts 1-800-333-8848				
ITEM NO.	PART NUMBER	DESCRIPTION		
1 2 3 4	129361 -870 129367 -617 129363 -928 146659 -008 or 366071 -996	RELAY, SOLID STATE RELAY, RV FUSE I/O BOARD ASSEMBLY		



NOTE: Units equipped with an Oasys Isolator do not include items 7, 8 and 9 at the middle and lower sections shown at the left for the Oasys end door.





Figure 4. Door Components

#### **DOOR COMPONENTS**

	Call STERIS® Customer Service For Ordering Parts 1-800-333-8848				
ITEM, NO.	PART NUMBER	DESCRIPTION			
1 2	764325 -922 146655 -827 129362 -260	DOOR GASKET REMOVAL TOOL (Not shown) DOOR GASKET PIN, Hitch			
	The second secon	DOOR DRIVE PACKAGE			
3 4 5 *6	93911 -444 136809 -103 136809 -104 93909 -954	CABLE ASSEMBLY MOTOR CABLE DRUM PROXIMITY SENSOR			
		DOOR OBSTRUCTION SENSORS			
7 *8 *9	129362 -344 93909 -894 93909 -895	COVER, Lens EMITTER ASSEMBLY RECEIVER ASSEMBLY			

<sup>\*</sup> STERIS® recommends this part be replaced only by a qualified technician, and suggests the customer call STERIS® for assistance. See page 1 for additional information.






Figure 5. Door Pressure Lock Assembly

#### DOOR PRESSURE LOCK ASSEMBLY

Call STERIS® Customer Service For Ordering Parts 1-800-333-8848			
ITEM NO.	PART NUMBER	DESCRIPTION	_`
1	146655 -865	PRESSURE LOCK	
*2	93909 -954	SENSOR, PROXIMITY	
3	93911 -202	CYLINDER	
4	129362 -334	WASHER (Silicone)	
5	R3500 -525	NYLON TUBING (Specify length when ordering)	•

1-13

<sup>\*</sup> STERIS® recommends this part be replaced only by a qualified technician, and suggests the customer call STERIS® for assistance. See page 1 for additional information.





Figure 6. Bridge Assembly and Rack & Shelving Assembly

### BRIDGE ASSEMBLY and RACK & SHELVING ASSEMBLY COMPONENTS

	Call STER	IIS® Customer Service For Ordering Parts 1-800-333-8848
ITEM	PART	
NO.	NUMBER	DESCRIPTION
1	146657 -206	TRACK ASSEMBLY, 26" Single Door
	146657 -207	TRACK ASSEMBLY, 26" Double Door
	146657 -208	TRACK ASSEMBLY, 39" Single Door
	146657 -209	TRACK ASSEMBLY, 39" Double Door
	146657 -210	TRACK ASSEMBLY, 49" Single Door
	146657 -211	TRACK ASSEMBLY, 49" Doub!e Door
	146657 -212	TRACK ASSEMBLY, 61" Single Door
	146657 -213	TRACK ASSEMBLY, 61" Double Door
2	93911 -224	CHAMBER DRAIN SCREEN
3	93911 -544	RAMP SLIDE
4	129367 -249	SCREW, PAN HD.
	150475 630	■ NUT, HEX
5	462328 -568	SCREW, PAN HD.
	150475 630	■ NUT, HEX
6	43224 -061	PIN ROLL
7	93911 -793	GUIDE BLOCK
8	150276 -001	SCREW, PAN HD.
9	129362 -870	SPRING
10	37675 -061	WASHER, FLAT
11	93911 -545	ROD
12	129362 -886	SCREW, PIVOT
13	191172 -061	NUT, JAM
14	146657 -503	SHELF, 26" UNIT
	146657 -644	SHELF, 39" UNIT



#### **OPTIONAL LOADING CAR**

O. HORAL LOADING VAIL				
Call STERIS® Customer Service For Ordering Parts 1-800-333-8848				
ITEM	PART			
NO.	NUMBER	DESCRIPTION		
4	440057 005			
1	146657 -605	SHELF WELDMENT - 26x26x26" - 2 per car		
	146657 -569	SHELF WELDMENT - 26x26x39" - 6 per car		
	146657 -569	SHELF WELDMENT - 26x26x49" - 8 per car		
	146657 -569	SHELF WELDMENT - 26x26x61" - 10 per car		
2	146657 -604	SHELF SUPPORT - 26x26x26"		
	146657 -603	SHELF SUPPORT - 26x26x39"		
	146657 -602	SHELF SUPPORT - 26x26x49"		
	146657 -601	SHELF SUPPORT - 26x26x61"		
3	136809 -612	GUTTER, SHELF SUPPORT - 26x26x26"		
	136809 -613	GUTTER, SHELF SUPPORT - 26x26x39"		
	136809 -614	GUTTER, SHELF SUPPORT - 26x26x49"		
	136809 -615	GUTTER, SHELF SUPPORT - 26x26x61"		
4	146655 -259	GATE, SIDE - 26x26x26"		
	146657 -150	GATE, SIDE - 26x26x39"		
	146657 -134	GATE, SIDE - 26x26x49"		
	146657 -202	GATE, SIDE - 26x26x61"		
5	93911 -584	AXLE		
6	129353 -321	RING, RETAINER		
7	47267 -091	WASHER, FLAT		
8	129367 -211	WHEEL		




Figure 8. Optional Transfer Carriage

### OPTIONAL TRANSFER CARRIAGE ASSEMBLY

Call STERIS® Customer Service For Ordering Parts 1-800-333-8848			
ITEM NO.	PART NUMBER	DESCRIPTION	
1	56396 -370	CASTER, Rigid	
2	56396 -369	CASTER, Swivel	
3	129353 -322	E-RING, RETAINING	
4	150828 -051	AXLE	
5	150828 -088	KNOB, PULL	
6	24496 -061	NUT, JAM, 3/8" - 16	
7	91536 -061	SPRING	
8	76666 -061	WASHER, FLAT	
9	36683 -061	ROLL PIN	
10	136809 -541	LABEL	
11	129362 -951	CARRIAGE LOCK SPRING	